



Studebaker

AUTOMOTIVE SALES CORPORATION
SOUTH BEND 27, INDIANA

Service Letter

PARTS AND SERVICE

SUBJECT ELECTRIC TYPE DOOR WINDOWS AND TAIL GATES
AVANTI AND STATION WAGON MODELS

FROM C. R. McIntosh, Manager
Passenger Car Technical Service

NUMBER J-1963-10

DATE February 15, 1963

The electric windows on the Avanti models and the electric tailgate window on station wagon models operate with the ignition key turned to the 'ignition position' only and will not operate with the key turned to the left or to the accessories side of the switch. If the electric windows are being serviced, the ignition switch is often left in the 'ON' position for an extended length of time. Prolonged operation of the electric windows can expose the distributor contact points to an abnormal load condition and result in severely burned points.

When it is necessary to service the electric door windows on Avanti models or the electric tailgate window on station wagon models, use the following procedure which will enable the windows to be operated without turning on the ignition switch:

1. Connect a jumper wire between the rear terminal (M) and the center terminal (B) of the window lift relay located on the left front fender apron.
2. Leave the ignition switch in the 'OFF' position and operate the window lift motors as required while servicing the windows.
3. Remove the jumper wire from the window lift relay after the servicing work is completed.

